



- To record TV shows, first, you will need to plug in the external USB storage devices such as the USB HDD (Hard Disk Drive) or USB flash stick to PHD-VRX.

PHD-VRX will promptly detect and mount the USB device. You can then press **QUICK** remote button to verify USB device status from Quick Menu. Or the USB device connecting screen will pop out first if some files are already in the USB HDD.



- PHD-VRX can record TV shows on the first USB device plugged in (internal system assigns it as “usba”). Second USB device plugged in (assigned as “usbb”) will be used as a general media player device.
- Make sure USB HDD for recording is formatted as either Linux ext-2 or Windows NTFS format. PHD-VRX provides on-screen format utility tool so you can directly format your HDD to Linux ext-2 for the best performance.



- To start recording, PHD-VRX provides four (4x) different recording methods in general:

### 1. **Record Now:**

This is the simplest recording method. Press the  remote button, and then select the “Record now” option. Instantly, PHD-VRX will start recording. You will see a red “R” running circle  displaying on the top right-hand corner of the TV screen to indicate that the current show is recording now. PHD-VRX will continue recording until you press **STOP** remote button to stop.



- To indicate recording in progress, the PHD-VRX unit front panel LED display will show:
  - “rEC-1” and red light for tuner 1 recording.
  - “rEC-2” and red light for tuner 2 recording.
  - “rEC-1-2” and red light for both tuner 1 and tuner 2 recording at the same time.



## 2. **Manual Recording associated with Program Guide:**

Press the  remote button and select the “Create a manual recording” option. If PHD-VRX detects the current TV show with Electronic Program Guide (EPG) data, PHD-VRX will automatically think you want to record this show from current moment to the end of the show. Once selected, the Record Schedule Timer screen will pop out. The active option is checked by default. All other options are greyed out and filled by EPG data except for “End Time”, in which the recording ending time can be increased from 1 minute up to 60 minutes’ delay.



Once you select “Done” to confirm the schedule timer, PHD-VRX will start immediately recording. You will see the red “R” running circle  on the top right-hand corner of TV screen as an indicator. PHD-VRX will automatically stop recording when the timer ends.



- Using this method to record the show if without EPG data, the Record Schedule Timer screen will open up all options and allow user to manually adjust them.

## 3. **Manual Recording:**

You can fully control how to schedule your recording by selecting this option from the main menu. Press **MENU** remote button to bring up main menu, then select Record → Schedule Recordings → Manual Schedule. Once selected, the Record Schedule Timer screen will pop out. In this point, majority options are open for user to adjust.



- **Active** option: Select this option to turn the schedule timer active and ready to record. You can also unselect this option to reserve this schedule timer and check back later in the “Upcoming Recording list”, see Page 5.
- **Type:** You can set different record schedule types as shown below.
  - **Once:** This record schedule will be used for only one time. The “Upcoming Recording list” will show  for this type.
  - **Everyday:** Selecting this type will force PHD-VRX unit to record the show at the same time every day. The “Upcoming Recording list” will show  for this type.
  - **Mon-Fri:** Selecting this type will force PHD-VRX unit to record the show at the same time during weekdays only. The “Upcoming Recording list” will show  for this type.
  - **Sat & Sun:** This type will force PHD-VRX unit to record the show at the same time during weekends only. The “Upcoming Recording list” will show  for this type.
- **Date and Time** options: You can adjust the recording starting time and date from these options.
- **Duration:** You can also adjust recording duration from this option. The minimum recording duration is 5 minutes (00:05).
- **Input:** Select recording schedule tuner input (Tuner 1 or Tuner 2).
- **Medium:** Select recording input RF source (Antenna or Cable).



The screenshot shows the 'Record Schedule Timer' interface with the following settings:

- Active:**  Active
- Type:** Once
- Date:** Jun 7, 2012
- Time:** 05:39PM
- Duration:** 01:00
- Input:** Tuner 1
- Medium:** Antenna
- CH:** 2-1
- Timer Options:**
  - Start:** On Time
  - End:** On Time
- Done** button

Since you can adjust the date/time and duration, Timer Options won't be available. Once you select “Done” and confirm, PHD-VRX will remember this schedule timer and display schedule information on the “Upcoming Recording list” (see Page 5).



You can either leave the unit on or turn off the unit to standby mode. Once the time is up, the unit will prompt a message and start recording, or wake up from the standby mode to start recording. The unit front panel will also show either “rEC-1” or -2 or both to indicate it is in recording progress.

## 4. Program Guide Recording:

There are two ways to start program guide recording. In menu, select Record → Schedule Recordings → Program Guide. This way, PHD-VRX will bring up Program Guide screen. Or, you can directly press **GUIDE** remote button to bring up the same screen.

In the Program Guide screen, use navigation keys UP and DOWN to search the desired channel. Then use RIGHT key to move to proper program title for recording.

If the highlighted program title is the very first one, which is the current show, then press  remote button. The “Record Options” screen will pop out. PHD-VRX will treat this recording the same way as method 1 or method 2 described on page 1 and 2.

If the highlighted program’s title is something other than the first one, it is a future show.

Press the  remote button, and a new “Record Schedule Timer” will pop out. In this screen, you can adjust Type, Start time and End time of the show per your preference. Once you select “Done” and confirm, the Program Title right side will be marked with type icons to indicate that this program is scheduled for recording.



- Once future schedule recording is set, you can either turn off the unit to standby mode or still keep the unit on. If the unit is on, you can still watch other TV shows from a different channel or from a different tuner. You can even switch to a different input. When time is up, PHD-VRX will automatically record the channel you previously set to.



- To check or modify record schedules from the “Upcoming Recordings” screen:

All recording activities including the current recording and future schedule recordings are all displayed from the Upcoming Recording list. To bring up this screen, press **MENU** remote button, then in Menu, select Record →Upcoming Recordings.

Move to the desired recording schedule and you can modify (Update) or delete the schedule.



Ch. Num	Ch. Name	Date	Time	Duration	Source	Status	Type	Active
ANT 5-1	KTLA-DT	Jun 08	23:00	00:30	Guide	R	Green	Yes
ANT 5-1	KTLA-DT	Jun 09	00:00	00:30	Guide	✓	Yellow	Yes
ANT 5-1	KTLA-DT	Jun 09	00:30	00:30	Guide	✓	Green	Yes
ANT 5-1	KTLA-DT	Jun 09	01:30	00:30	Guide	✓	Red	Yes

CC NC-17

**Friends**  
The One With Joey's New Girlfriend: Chandler falls for a woman who is already involved with Joey; Rachel and Ross play the jealousy game.

Select Update Delete Page Up Page Dn Exit

The “Status” column indicates the current recording status:

- R** : Recording in progress.
- ✓ : Will record soon.
-  : USB device unplugged.
-  : Not enough memory size to record.
-  : Recording is forced to stop.
- X** : Recording error.



- Once you set a schedule, it is always good to check back from this “Upcoming Recordings” screen to confirm that you have successfully set up a timer recording schedule.
- You can set up to a maximum of **32** different recording schedule events. Once a recording is complete, then this recording information will be removed from the list.

- To check the recorded TV program from “Recorded Shows” screen:

This “Recorded Shows” screen holds the history of your recorded shows and contains all TV program status, file names and detailed program description if it is available from program guide. To bring up this screen, press **MENU** remote button, then in menu, select Record →Recorded Shows.




Ch. Num	Ch. Name	Date	Time	Duration	Status	File Name
ANT 7-1	KABC-DT	Jun 09	11:30	00:17	✓	EVERYDAY-HEALTH_692012_114256.mpg
ANT 5-1	KTLA-DT	Jun 09	00:30	00:30	✓	Family-Guy_692012_003010.mpg
ANT 5-1	KTLA-DT	Jun 09	00:00	00:30	✓	Family-Guy_692012_000003.mpg
ANT 5-1	KTLA-DT	Jun 08	23:00	00:30	✓	Friends_682012_230003.mpg

- File names used for recorded shows are named by the following two conditions:
  - (1) If the show has Electronic Program Guide (EPG) data associated with it, the file name will add program title first followed by the date and time. For example,
 

File name: **KTLA-5-News-Sunday-Edition\_5272012\_200048.mpg**

The recorded program title is “KTLA-5-News-Sunday-Edition”, and it is recorded on May (05), 27<sup>th</sup> in 2012. The recording started at 8:00pm 48s.
  - (2) If the show has no EPG data associated with it, the file name will add the channel number first followed by the date and time. For example,
 

File name: **52.1\_512012\_221850.mpg**


The program is recorded from channel number 52.1 on May (05), 1<sup>st</sup> in 2012. The recording started at 10:18pm 50s.
- To play back recorded programs, you will need to go to the “Media Player” menu and select “Video” to play.

- To play recorded shows from the Media Player menu:

You can access PHD-VRX Media Player menu to play back all video, music and photo files from USB HDD or a USB flash stick. The recorded TV shows from PHD-VRX are those files with the extension of .mpg, which can be accessed under Video section. To play these files, press **MENU** remote button, then in Menu, select Media Player → Video.



A new “Video” menu screen will come out. On the left side of the screen is the list showing all recognized video files including recorded TV shows. On the top portion of the right side is the preview window for the video file you currently highlighted. The right side bottom portion shows a video time line and action keys.



Press **OK** remote button for the highlighted file. The full size video will be displayed.

For both small preview video and full size video, you can use remote control action buttons to adjust the speed or stop the video at any time. These action control buttons are:



-  **PLAY:** Play or resume a paused video.
-  **PAUSE:** Pause current video.
-  **STOP:** Stop playback.
-  **FORWARD SKIP:** Use for commercial skip or quick video jumping. Press this key once to generate a 20 second forward skip. Press and hold this key to create steady 20 second increments of continuous video forwarding.

-  **BACKWARD SKIP:** Use for commercial skip or quick video jumping. Press this key once to generate a 20 second backward skip. Press and hold this key to create continuous 20 second decrements of video rewinding.
-  **RWD:** Rewind video quickly. Press this key multiple times to create 2x, 4x, 8x, 16x, and 32x different rewind speeds.
-  **FF:** Fast Forward video quickly. Press this key multiple times to create 2x, 4x, 8x, 16x, and 32x different fast forward speeds.



- When using the Media Player function to play back video, music or photo files, PHD-VRX unit front panel LED display will show “PLAY” to indicate that the unit is in playback mode.

- To record TV shows from both tuners:

No matter which recording methods you are using, you can record two shows from two tuners at the same time. After recording one show in tuner 1 for example, or setting up a schedule timer for a tuner 1 program, you can switch to tuner 2 by pressing the **INPUT** remote button. The “Inputs” screen will pop up. Use the UP or DOWN key to select either Tuner 1 or Tuner 2 and press **OK** remote button to switch.

Or, you can simply press **TV** remote button to toggle between Tuner 1 or Tuner 2 input. Switch to a different Tuner, then start setting up a recording method, as detailed on pages 1 to 4, as usual.



Note: Please always use  key as the ‘**BACK**’ or ‘**RETURN**’ key when needed.