

INSTALL SUPERIOR MARK™ FLOOR MARKING BOX IN LESS THAN 5 MINUTES

Featuring Easy To Install Pre-Cut Strips of Superior Mark™ Floor Marking Material

Before installing, clean the floor with alcohol based cleaner. Let dry completely, then mark a guide to ensure proper alignment.


Step 1: Peel and stick down middle section of box.

Step 2: Align puzzle cut edges and stick down one side of the box.

Step 3: Align the third strip to complete the box.

Step 4: (Optional) Peel and stick down a floor sign.

First time customers can receive a free electrical panel floor marking kit. Some conditions apply. Call 1-866-284-1541 for details.



Pre-cut boxes are made with Superior Mark™ brand floor marking tape, which features beveled edges and recessed adhesive for maximum durability. Pre-cut floor marking boxes are available in any size, and floor signs can be custom printed any size, shape, or design.