

Battic Door

Home Energy Conservation Products

R-50 ATTIC STAIR COVER INSULATION KIT INSTALLATION INSTRUCTIONS

Please Read Instructions Carefully Before Beginning Installation



1. Bring assembled stair cover and R-50 Kit components into the attic.



2. Open reflective shield and insert both pieces of insulation.
If providing your own insulation use multiple layers 12-16" deep.



3. **IMPORTANT!** The shield fits tightly around the stair cover box. GENTLY insert the stair cover box (open end up) into the reflective shield by slipping the stair cover box CAREFULLY into the shield. Pull each corner of the shield about 1" at a time, moving from corner to corner.



4. Position stair cover over the weatherstrip seal as you exit the attic.

TIP: If desired, additional insulation may be added to the sides of the stair cover between the shield and the cover if clearance allows.

THANK YOU FOR YOUR PURCHASE

info@batticdoor.com www.batticdoor.com 508.320.9082