

**Wireless Indicator**

Shows Status of your Wi-Fi or Cellular Data Signal



**Wi-Fi Active**  
"You are Connected"



**3G Cellular Data Active**  
"You are Connected"

**Headphone Jack**

On top edge

**Power/Sleep button**

button

**Battery Strength**

(Plug shows charging)



**Screen Rotation Lock switch**

Lock switch

**Volume Up & Down keys**

Press & hold Volume down for Mute

**Calendar**

Shows Day & Date (Saturday the 1<sup>st</sup>)



**Settings**

Adjust Date, Time, Connect to Wi-Fi/3G, Change just about anything



**App Store**

Add games and other cool Apps. (Shows 2 Apps need updates)



Set this picture in Settings > Brightness & Wallpaper



Each dot is a Screen of icons. Swipe left/right.

3 dots = 3 pages

Swipe left to get to Spotlight Search

**Bottom Dock**

These icons are always visible. Lock up to 6 icons here.

**Tip:** Press and hold an icon to move it down to this dock.



**Home button**

Press to return to Home Screen. **Tip:** Double-click for iPod controls and more.

**Speakers**

Three holes on bottom edge

**Charging / Sync / Dock Port**

Connect to PC/Mac or Dock

