

## Floor Cleaning Products Application Instructions

### InSite Solutions Floor Degreaser

- Concrete / Floors: Add 4 ounces of InSite Solutions Floor Degreaser per gallon of water. Apply freely to the floor or hard surface with a mop or scrub brush. Pick-up and rinse with clean water.
- Light / Medium Soils: Add 4 ounces of InSite Solutions Floor Degreaser per gallon of water. Apply to surface and allow to penetrate. A light scrubbing action will increase cleaning effectiveness. Rinse thoroughly with clean water.
- Heavy Soils: Mix one part InSite Solutions Floor Degreaser to one part water for tough to remove soils. Apply to surface and allow to penetrate until soils have been loosened. Scrubbing actions will increase cleaning effectiveness. Repeat if necessary. Rinse thoroughly with clean water.
- Floor Machine Application: Mix one part InSite Solutions Floor Degreaser to one part water. Apply freely to surface. Let sit 5-10 minutes before agitating surface with floor machine. Pick-up and rinse with clean water.

### InSite Solutions Adhesive Remover

- Spray InSite Solutions Adhesive Remover on the surface. Let sit for 1-2 minutes. Heavy build-ups may require longer times or more InSite Solutions Adhesive Remover. Wipe clean with InSite Solutions Floor Degreaser or a damp cloth with water.

Caution: InSite Solutions Adhesive Remover may begin to remove paint from painted surfaces.

Newly formulated to meet California and OTC Standards

### InSite Solutions Paint Remover

- Apply a thick layer of InSite Solutions Paint Remover to the coating to be removed by pouring, brushing or airless sprayer. If applying by brush do not apply as you would paint. Lay on a thick even layer up to 1/8 of an inch.
- Don't brush or scrape the surface until the remover has had the time to work. Check the progress of the stripping action by using a scraper to see if the coating is softened down to the surface. If not, wait longer and recheck. As long as the remover is wet, it is working. Longer is better. Let the remover do the work.
- Once the coating is softened, remove it with a scraper or other stripping tool. Reapply remover, if necessary. Repeat steps above.
- After use, clean remaining thin residue with InSite Solutions Floor Degreaser, using a cloth or fibrous scrub pad. Allow surface to dry before further preparations.