smudger

J B B P R UTS

TOUCHSCREEN ERASER | pocket size

smudger



How it works.

Simply remove the clear cap and begin wiping the fabric tip across your touchscreen. Use short quick wiping motions in a variety of directions - similar to erasing a chalkboard. It's easy, smart, and just plain fun to use.



TOUCHSCREEN ERASER | pocket size

The sleek new way to remove fingerprints and smudges from your touchscreen without chemicals or sprays. In just a few quick swipes you'll have a beautiful view of your photos, apps and videos. Best of all, it slides neatly into your pocket so you can take it anywhere.



It fits in your pocket.

Tuck it in your pocket or purse. The Smudger[™] Touchsceen Eraser is so small and discreet you won't even know it's there until you need it. Go ahead and take it everywhere.



The fabric wiping blade is replaceable.

When your Smudger[™] Touchscreen Eraser is ready for a fresh new replacement blade - simply insert a new fabric blade into the eraser's base. *Additional replacement blades sold separately.



Keep all your devices smudge-free.

The Smudger[™] Touchscreen Eraser cleans just about any glossy touchscreen device. It's never been easier to keep your smartphones and tablets smudge-free...on the go. enjoy a beautiful view

www.smudger.com