

SENSEI

“How To Get The Most From Your Pruning Shears”



FREE VIP Club

Get Samples, Exclusive
Discounts, Special Events
& Win Free Stuff!

JOIN HERE:

sensei-tools.com/vipclub



Introducing The Sensei Professional Pruning Shears



We have taken the classic design for hand pruning shears, and refined it. With top quality materials, and the classic Sensei attention to detail, we predict you'll love them!

These Pruning Shears feature virtually indestructible drop forged aluminium handles, which are much stronger than those found on normal pruners.

They're coated with a non-slip finish for a secure, safe grip.

The blades are made of extra-strong SK5 carbon steel, chrome plated to prevent rust and reduce friction for an easy, clean cut, every time.

The blades also have a cutting notch for cutting thin stems or pieces of wire (so you don't damage the blades), and sap groove to keep the blades clean and sap-free.

The design is comfortable to hold, and equally suits men and women's hands.

Pruner length: 8.5". Recommended cutting diameter: 22mm

And as always they come with our full 100% manufacturer's no-quibbles lifetime warranty.

Using Your Pruners



Once you start to use your Pruning Shears you'll quickly find that they become an indispensable tool.

Hold the branch you want to cut firmly, without twisting or pulling. With your other hand, use the pruning shears to snip the branch with a nice clean cut.

When cutting, open the pruners enough that the whole branch fits between the blades, so that you can cut in one clean motion. Use the deepest part

of the blade that you can to get maximum leverage when you cut – this will make it easier for you and reduce strain on your arm.

Use the wire-cutting notch at the base of the blade if you want to cut wire. Never cut wire using any other part of the pruners or you will nick the blade.

We recommend wearing gloves when pruning, to protect your hands from scratches by branches and thorns

Looking After Your Pruning Shears

Your Pruning Shears are made to last, and a bit of simple maintenance will keep them in top condition for years and years.

We recommend a quick clean after each use. Simply rinse with water, and then dry with a cloth or paper towel (please take care not to cut yourself on the blade)

If necessary you can wash the blade and handle with soapy water, but please don't use chemical cleaners or white spirit that could damage your pruners.

To keep the blade in perfect condition, apply a thin coating of oil before storing somewhere clean and dry.

Sharpening: The blade will hold its edge very well, and shouldn't need frequent sharpening, but you can sharpen it if necessary using any commercial sharpener.

Thanks & Feel Free To Reach Out!

Finally... Thanks for supporting our small family run business. If we can be of ANY assistance or if you have questions, please email me! All emails come to me directly and we will take good care of you.

Finally, on the last page you will find 2 special Coupons for *Sensei* products

Sincerely,
Neil King
Founder: Sensei

* Special Limited Time Coupons *

As our way of saying "THANK YOU", we are including a special *customer appreciation Coupon* that can be used on Amazon. If you find yourself enjoying this product, then you will love this complimentary product below. Search Amazon for it, and enter the coupon code at checkout. *Expires soon so take advantage of the special discount now.*

20% DISCOUNT On The Sensei Hori Digging Knife



Go to Amazon and Add Item to Cart. Enter Coupon Code Below at Checkout to Save 20%

HORI2020

20% DISCOUNT On Sensei Professional Pruning Shears



Go to Amazon and Add Item to Cart. Enter Coupon Code Below at Checkout to Save 20%

20PRUNER