

- To use PHD-VRX timeshift and live pause features, first, you will need to plug in the external USB storage devices such as the USB HDD (Hard Disk Drive) or USB flash stick to PHD-VRX unit.

Once plugged, PHD-VRX will promptly detect and mount the USB device. You can then press **QUICK** remote button to verify USB device status from Quick Menu. Or the USB device connecting screen will pop out first if some files are already in the USB HDD.



In order to create timeshift on live TV program, PHD-VRX will generate and store a “timeshift.mpg” file first to the external USB device.

PHD-VRX also provides several timeshift durations (5, 10, 20, 30, and 60 minutes) to choose. The timeshift duration is like a time buffer. Within this duration, you can shift the program backward, forward or pause at any point you prefer. You can also choose the proper timeshift duration based on your external USB HDD size since larger timeshift duration will generate bigger HDD storage space. The default duration is 5 minutes.

There are two ways to adjust timeshift duration. Press **QUICK** remote button to bring up Quick Menu. In this menu, move to “Timeshift Duration” option and then use navigation keys LEFT and RIGHT to change the proper duration time. Or, in menu, select Record → Timeshift Duration. Then use navigation keys to choose the duration time.



- PHD-VRX can access timeshift.mpg file only from the first USB device plugged in (internal system assigns it as “usba”). Second USB device plugged in (assigned as “usbb”) will be used as a general media player device.
- Make sure USB HDD is formatted as either Linux ext-2 or Windows NTFS format for timeshifting. PHD-VRX provides on-screen format utility tool so you can directly format your HDD to Linux ext-2 for the best performance.





■ To start timeshifting, watch a live TV show from either PHD-VRX tuner 1 or tuner 2. Then press the  remote button. The “Start Timeshift” screen will pop out. Once selected “Yes”, you will see a red “R” running circle  displaying on the top right-hand corner of the TV screen to indicate that the timeshifting function is now in progress.

In the same time, you will see timeshift information screen displayed on the bottom of TV screen.

From inside of timeshift information screen, there is the time line for timeshift progress bar. Green bar indicates the current moment that you are watching now from TV. Blue bar indicates of the real live TV show displaying moment.


Now, you can use remote control action buttons to adjust the speed and pause, or stop the video at any point you prefer.

These action control buttons are:



- ▶ **PLAY:** Play or resume current paused video.
- ⏸ **PAUSE:** Pause live TV or pause current video.
- ◀◀ **RWD:** Rewind video quickly. Press this key multiple times to create 2x, 4x, 8x, 16x, 32x, 64x, 128x, and 256x different rewind speeds.
- ▶▶ **FF:** Fast Forward video quickly. Press this key multiple times to create 2x, 4x, 8x, 16x, 32x, 64x, 128x, and 256x different fast forward speeds.
- ◀◀ **SLOW BACKWARD:** Slow motion of rewind video. Press this key multiple times to create 1/2x, 1/4x, 1/8x, 1/16x, 1/32x different rewind speeds.
- ▶▶ **SLOW FORWARD:** Slow motion of forwarding video. Press this key multiple times to create 1/2x, 1/4x, 1/8x, 1/16x, 1/32x different forward speeds.
- **STOP:** Stop timeshift.

Either press the  or  remote button again to stop timeshift function. "Stop Timeshift" screen will pop up. To confirm of stop timeshifting, select "Yes" option.



- To indicate timeshifting in progress, the PHD-VRX unit front panel LED display will show:
 - "rEC-1" and red light for tuner 1 timeshifting.
 - "rEC-2" and red light for tuner 2 timeshifting.
- If no any action control button pressed in a certain period of time, timeshift information screen will automatically time out. Press any action control button again, timeshift information screen will re-appear. Or, press **QUICK** remote button to bring up Quick Menu. Then select "Timeshift Status" option to bring up timeshift information screen again.



Note: Please always use  key as the 'BACK' or "RETURN" key when needed.